

Tips for Kawasaki Ninja Flushmount signal installation.

1.)I recommend that you remove the mid-fairings to help simplify installation.

2.)Remove the stock turn signals and simply push the new signals into the recess in the fairing.

DO NOT PUSH ON THE AMBER BULB, PUSH ONLY ON THE LIGHT HOUSING!!!!

3.)Use the 3mm screws to clamp the signal into the fairing. The screws install from the backside after the signal has been fully inserted into the recess in the fairing.

4.)The RED wire is positive and the BLACK is negative. The LED's will not work if they are wired backwards.

Thanks for your purchase. E-mail Gregg@greggscustoms with any questions/concerns.